

Adirondack Wooden Chair Instruction Manual

For correct usage, please read these instructions carefully before assembly and keep in a safe place for future reference.

General information and safety warnings

- Make sure that all parts are present before beginning assembly.
- Assemble on a flat safe surface; do not assemble on sloping ground.
- Do not fully tighten all nuts and bolts until the chair has been fully assembled.
- Store in a cool dry place when not in use like a shed or garage.
- It is advisable to store away during wet weather or freezing temperatures.
- Only one person should sit on the chair at a time.
- This chair is not designed for commercial use.
- Do not allow children to play on the chair.
- To prevent tipping do not throw your weight against the back of the chair.
- Maximum user weight is 113kg (250lbs) .
- **The Adirondack chair is provided untreated; to preserve and maintain the wood, we recommend that you treat it with an exterior wood paint, varnish or stain.**
- **To maintain the finish of the chair, it may be necessary to recoat annually - follow the recommendations of the specific product used.**


















Chair Measurements

Length 91cm

Width 77cm

Height 87cm



Parts	Assembly
<p>(A)  Seat Panel x1pc</p>	<p>NOTE: KEEP ALL NUTS AND BOLTS LOOSE DURING ASSEMBLY</p> <p>STEP 1</p> 
<p>(B)  Back Panel 1pc</p>	<p>STEP 2</p> 
<p>(C)  Right Leg x1pc</p> <p>(D)  Left Leg x1pc</p>	<p>STEP 3</p> 
<p>(E)  Right Arm Rest x1pc</p> <p>(F)  Left Arm Rest x1pc</p>	<p>STEP 4</p> <p>TIGHTEN ALL NUTS, BOLTS, & SCREWS LAST</p> 
<p>(G)  Front Support Beam x1pc</p> <p>(H)  Back Vertical Support x2pc</p> <p>(I)  Nuts & Bolts 2.8" (70mm) x2pc</p> <p>(J)  Nuts & Bolts 2" (50mm) x14pc</p> <p>(K)  Screws x10pc</p>	
<p>Tools Required (not included)</p> <p>10mm Wrench Phillip Screwdriver</p>  	




Adirondack Wooden Chair Footrest Instruction Manual

For correct usage, please read these instructions carefully and keep in a safe place for future reference.

- Make sure all parts are present before assembling.
- Do not fully tighten all nuts and bolts until the footrest has been fully assembled.
- Assemble and use on a flat surface; do not assemble or use on sloping ground.
- Store in a cool, dry place when not in use, a shed or garage for example.
- It is advisable to store away during wet weather or freezing temperatures.
- Never sit or place heavy objects on the footrest.
- Do not allow children to play with the footrest.
- The Adirondack footrest is provided untreated; to preserve and maintain the wood, we recommend that you treat it with an exterior wood paint, varnish or stain.
- To maintain the finish of the footrest, it may be necessary to recoat annually – follow the recommendations of the specific product used.


Parts & Assembly

You will require 10mm wrench and a Philips screwdriver which are not supplied.




NOTE: KEEP ALL NUTS AND BOLTS
LOOSE DURING ASSEMBLY

STEP 1



STEP 2



TIGHTEN ALL NUTS,
BOLTS, & SCREWS
LAST